

comfort

Infrared light emitted by the sun passes through polycarbonate sheet making it warm underneath. Comfort Cool™ Technology reflects the heat away whilst letting visible light through with




How it works

UV rays, wind, hail and rain have the potential to make polycarbonate resins brittle and lose colour over time.

Advanced Weatherquard" protects the sheet and protects from








laserlite.com.au

scan this QR code for more info

# Performance & Reliability

## The classic, high performing Laserlite® range.





### Lengths Available

1.8m, 2.4m, 3.0m, 3.6m, 4.2m 4.8m, 5.4m, 6.0m, 7.2m, 9.0m



Sheet Width Corrugated 840mm Greca 810mm 5 - rib 830mm Cover Width Corrugated 755mm Greca 765mm 5 - rib 762mm

# **Ultimate Comfort**

## Technologically advanced heat reflective range.



Based on the warming effect of the sun's rays through a sheet vs 3mm float glass (300-2500nm), #As compared to some other polycarbonate corrugated sheet product

### Installation Guide



### Purlins & Accessories



1. Ensure that your roof pitch is at least 5°, i.e. 88mm rise per lineal metre. This will ensure adequate water run off.



condensation in odd weather,

3. For mofing pull-lostents spacings should be no more than those shown in Table X. - Maximum Pull of Spacings, For curved structures, the maximum pulln spacing, should be 750mm and a minimum radiac of 4000mm for 581 point and Greea profile and 14000mm for 581 point of the rowsten copyling spacings should be no more that 1200mm, Use Lasefille? Nose Stop Tape on all batters, pullner of noggings to immime the noses associated with expansion and contraction.

4. Lay Laserlite<sup>®</sup> Noise Stop Tape to avoid

Lay Laserlite<sup>®</sup> Eave Infill Strips at eaves to avoid rain, dust & wind entering the eaves.

6. For installations under a gutter, fit metal back channel with Back Channel Infill Strips prior to

Table X - Maximum Purlin Spacings 
 Profile
 End Span
 Mid Span

 Corrugated
 800mm
 1000mm

 Greca
 900mm
 1200mm

 5 Rib
 900mm
 1200mm



 Ensure that the UV surface protected side faces the sun. This is the side of the label and the inkjet marking. When installed as a wall or fine intermaking, when installed as a wail of fence it is recommended that the UV protected side is facing the most sun. The life of the sheet may be shortened and discolouration may occur due to the unprotected side being exposed to UV redistion. 2. The sheet can be easily cut with a pair of shears, a fine-toothed handsaw or a circular saw with a cut-off blade suitable for plastic.

3. For roof laying, start with the lower sheets first, keeping side laps away from prevailing wind. Allow an overhang of Somm. Temperature changes will cause expansion and contraction, so make allowances for themal movement. Resistance to movement can cause buckling.

4. Side laps will differ by profile. Install as shown



5. To ensure maximum performance of the sinest, and to avoid buckling, it is necessary to enversible the helps and centre the fidings, it is recommended that Laserlies' Thos Short' Surga et used. They come complise with their own in the source of the sinest service of the sinest servic

to be compatible with Laserfle® Polycarbonates
Faciling. Any falling of the sheet due to fixings
other than Laserfle® Pontanded will void the
Laserfle® warranded will red approximately?
As a guide, you will need approximately 7
kings per lineal mere. This depends on your
purin spearing and wind conditions, in high
wind areas for Corrugated and Green on every
second corrugation on each puril-voiders. It is
supplied that being capting to sease. Fix the
supplied will be page capting to sease. Fix the
Standard Foungs
Standard Foungs
Standard Foungs

Table Z - Fixing Spacing

Profile End Purlin Mid Purlins
Corrugated every 2nd crest every 3rd crest
Greca every 2nd crest every 3rd crest
5 Rib every crest every crest

Using One Shot<sup>®</sup> fixings eliminates requirement

Step 3



for various installations

APEX ROOF - Fit metal barge capping\* to the





AGAINST A WALL/FASCIA - Fit metal barge capping to edge of sheet and metal apron flashing at the wall or fascia.

### Safety Recommendations

- Always exercise extreme care when walking on a roof. Never walk on or apply your load directly to

- Never wals or or apply your load directly to heading.

  In particular consider all safety requirements when working at heights above 2m.

  In particular consider all safety requirements when you was a considerable or considerable or of alley mesh for installations above 3m. Use approvale personal protective equipment (PPE) such as safety lookwear, glasses and gloves uset comply, with the applicable local building and/or work cover code(a).
- we do not recommend and conlection of drinking water from any roof without appropriate precautions and filtration. Check with your local water authority for further advice.